

# Barcode Scanner User Manual



W010F01  
Start

## Introduction

This user manual is quick start manual. For detailed manual information, please download the complete user manual from our website or obtain it from our distributor.



W010F01  
Start

## System Setting



WFFD980

Reset (Return to factory default)



W070902

USB virtual serial



W070903

USB-POS



W100900

RS232 serial port



W100910

PSS-KBW

## Communication Interface



W070901

USB-KBW



W010F01  
Start

## Baud Rate



WFFD9D0

1200



WFFD9D2

4800



WFFD9D3

9600 \*



WFFD9D5

19200



WFFD9D6

38400

## Serial Parameters



W010F00

End



W010F00

End



V6.6.1



W010F00

End



W010F00

End



W010F00

End



W010F01  
Start

Parity Check



W062900  
None \*



W062904  
Odd parity



W062906  
Even parity

Data bits



W082900  
7 Bits



W082908  
8 Bits \*



W010F00  
End



W010F01  
Start

### Keyboard mode

Keyboard case control



W381A000  
Default \*



W381A20  
Uppercase



W381A30  
Lowercase

Keyboard Language



WFF1900  
USA \*



WFF1907  
French



W010F00  
End



W010F01  
Start



WFF1919  
Turkish 1



WFF191A  
Turkish 2



WFF191B  
English

### Barcode Enable and Disable



WFFD981  
Enable all Barcodes



WFFD982  
Disable all Barcodes



W016100  
Disable Code 128



W010F00  
End



W010F01  
Start



W016101  
Enable Code 128



W0FFD990  
Restore Code 128 default setting



W036203  
Enable UCC/EAN-128



W036200  
Disable UCC/EAN-128



W036300  
Disable AIM128



W036302  
Enable AIM128



W010F00  
End